

Upper Shock Mount (MMSM-20)



Read all instructions before beginning work. Following instructions in the proper sequence will ensure the best and easiest installation.

Supplemental Installation Notes

- Follow the MMD-RC0xxxx or MMD-RC1xxxx shock installation instructions included with your shocks. They provide detailed steps on how to install the components from the MMSM-20 Upper Shock Mount Kit.

This Kit Contains

Description	QTY
Dust Boot Assembly	1
Shock Top Bushing	2
Upper Retaining Washer	1
M10-1.5 Nylock Nut	1

Component Identification

M10-1.5 Nylock Nut



Dust Boot Assembly



Shock Top Bushing



Upper Retaining Washer

