

---

### *SVO Master Cylinder Adapter Fitting (MMBAK-1)*

---



5. Bleed the brakes per your service manual.
6. Have a friend firmly depress the brake pedal and inspect all fittings for leaks.
7. Test drive, and enjoy.

*Read all instructions before beginning work. Following instructions in the proper sequence will ensure the best and easiest installation.*

1. Remove your stock master cylinder, and instal the SVO Mustang master cylinder.
2. Install the adapter fitting MMBAK-1 into the forward port of the master and tighten firmly.



3. Thread the rearward line directly into the rear port. Tighten firmly. Use a flare wrench to avoid rounding off brake fittings.
4. Thread the forward brake line into the MMBAK-1 adapter fitting. Hold the previously tightened MMBAK-1 fitting with a wrench while firmly tightening the brake line with a flare wrench.