

MM Strut Tower Brace, 1998 Cobra (MMSTB-4)

MMSTB-4 is for 1998 Cobra's without a factory strut tower brace.

Read all instructions before beginning work. Following instructions in the proper sequence will ensure the best and easiest installation.

The MM Strut Tower Brace attaches to each strut tower and to the firewall.



1. Remove the windshield wiper arms.
2. Raise the hood.
3. Set the MM Strut Tower Brace into position. The brace will settle into position on the strut towers and the firewall when it is positioned evenly side to side.



4. Mark the position of the strut tower brace on the plastic covering the firewall.



5. Remove the alarm siren (if so equipped) from the firewall. Then remove the plastic cover from the firewall. It is held on with several small sheet metal screws, as well as the hood seal.



6. Cut out the portion of the plastic you marked.

Tip: use a hacksaw on the vertical cuts. Use a utility knife to score the plastic on the horizontal cut, then bend and break the plastic on the scored line.



7. Put the plastic back into position on the firewall. Set the Strut Tower Brace back into position and check that the plastic is notched correctly.



8. Jack the front of the car up and set it securely on stands.
9. Position the Strut Tower Brace. Hold the brace downwards and rearwards. Mark the position of one slot on the passenger side strut tower top. Remove the Strut Tower Brace.

NOTE: Try to mark the center of the slot.



10. Center punch the mark. Drill a 1/8" pilot hole. Drill out to 5/16". Deburr the hole.



11. Set the Strut Tower Brace back into place. Insert a 5/16" bolt into the hole to hold the brace in position. Hold it both downwards and rearwards. Mark the positions of all of the other holes on both strut towers. Remove the Strut Tower Brace before drilling.



12. Center punch each mark. Drill a 1/8" pilot hole. Drill out to 5/16". Deburr the holes.

13. Remove the plastic cover from the firewall.

14. Remove the 5/16" bolt securing the 'A' pillar applique. It is located above the door hinge. The door must be open to access the bolt. Do this on both the Driver and Passenger sides of the car.



15. DO NOT remove the applique. Gently move it away just enough to open a small gap for removal of the plastic cowl at the base of the windshield.



16. Remove the plastic cowl cover at the base of the windshield. It is held on with clips. Remove it by gently prying it upwards. When it is loose, disconnect the hose to the windshield washer nozzles (pointed to below).



17. Place the Strut Tower Brace back into position. Place the larger outer diameter flat washers under the heads of (6) 5/16" x 1" long bolts. Place the bolts through each of the holes at the strut towers. This is for positioning only. Do not install the nuts.

18. Hold the brace down and rearwards. Mark the position of the 8 holes at the firewall.



19. Remove the 6 bolts at the strut towers. Remove the Strut Tower Brace.

20. If necessary, remove the air inlet from the throttle body. That allows more room for the drill motor to be correctly positioned while drilling the holes for the passenger side firewall tube.




21. Drill the holes at the firewall. Start with a 1/8" pilot bit. Drill out to 5/16" and deburr the holes. Note: Hold the hood vertical when drilling downwards into the pinch weld. That will provide clearance for the drill motor. *Tip:* Hold the hood upright by using a rope or strap to tie the hood to the steering wheel.



22. Install the 5/16"-18 x 3/4" long bolts in the nut plate. Thread them through so that they protrude on the flat side of the nut plate. It is not necessary to thread the bolts all the way in.



23. Line up the nut plate on the 5/16" holes drilled in the firewall in Step 20. Use the bolts installed in the previous step as guide pins. Make sure that the small hole in the plate is biased downward.



24. Using the nut plate as a template, mark the location of the small hole using a scribe or punch.

25. Remove the nut plate from the firewall.

26. Drill a 1/8" pilot hole on your mark.

27. Drill the hole out to 3/16".

28. Deburr the hole.

29. Remove the 5/16"-18 x 3/4" long bolts from the nut plates.


30. Install the nut plates behind the firewall. The flat side should be against the firewall, with the nuts toward the rear of the car. Make sure the small hole lines up with the 3/16" hole drilled in Step 27. Thread the 5/16"-18 x 3/4" long bolts into the nut plate to keep it from rotating when the sheet metal screw is installed.



Tip: On the Driver's Side, tape the nut plate to a screwdriver to help hold it in position behind the firewall while installing the bolts.



31. Install the #8 sheet metal screw into the small hole in the nut plate. Remove the 5/16"-18 bolts.



NOTE: This will secure the nut plate to the firewall, making future removal and reinstallation of the Strut Tower Brace significantly easier. The head of the sheet metal screw should line up with the hole at the back of the strut tower brace mounting pad.

32. Set the Strut Tower Brace back into position.
33. Insert all of the attachment bolts into position and start all of the nuts before fully tightening any of the bolts.
34. Tighten the 5/16"-18 x 3/4" long bolts into the nut plates at the firewall.



35. Tighten the bolts at the pinchweld.
36. Tighten the bolts at the strut towers.

NOTE: Use the 6 provided large outer diameter flat washers underneath the head of the bolts.



37. Reconnect the hose for the windshield washer nozzles. Reinstall the plastic cowl cover at the base of the windshield by gently snapping it back into position on its clips. Make sure the outer edge of the plastic cowl cover slips past the 'A' pillar applique and into its correct position. Reinstall the 'A' pillar applique bolts previously removed in Step 14.
38. Reinstall the firewall plastic cover. Put the passenger side into position first, making sure to place it into proper position underneath the ground strap. Secure with the retaining screws.
39. Re-install the rubber weather-stripping.

40. Reinstall the alarm siren, if so equipped.



Hardware Kit:

- 10 5/16-18 x 1" Hex Bolts
- 4 5/16-18 x 3/4" Hex Bolts
- 24 5/16 Washers, G8 (**Only 18 are needed**)
- 6 Flat Washers
- 10 5/16-18 Nylock Nuts
- 2 Nut Plates
- 2 Sheet metal Screws

41. Carefully lower the car to the ground.

NOTE: Access to the fuse box-- The cover can still be opened by pulling the cover forward past the strut tower brace main tube as you lift the cover.



NOTE: If the fuse box cover cannot be opened, reposition the fuse box by moving it forward. This can easily be done by slipping a screwdriver between the front of the strut tower and the rear of the metal fuse box mounting tabs (these are attached to the strut tower). Gently pry the tabs forward. This will move the fuse box slightly forward.

